



ANTI-SLIP SOLUTIONS

mail@heskins.com

www.heskins.com

01/10/2015

Instructions for H3508 IPA usage

1. Ensure the substrate is dry.
2. With a clean, dry rag or cloth (inexpensive J-cloth types are ideal) soak the cloth with H3508.
3. Wipe the substrate using the soaked cloth, try not to use an irregular 'windscreen wiper' method, the best solution is to make continuous sweeps in the same direction, the H3508 does not destroy contaminants it merely lifts them and deposits them elsewhere.
4. The H3508 will dry in approximately 5 minutes dependent on temperature.
5. The safety-grip can be applied onto the substrate once dry.